## Introduction

• Johnson-Nyquist noise (thermal noise) is the electronic noise generated by the thermal agitation of the charge carriers inside an electrical conductor at equilibrium,

which happens regardless of any applied voltage.

- Johnson noise for a resistor depends on temperature as predicted by the equation  $\langle v^2_J(t) \rangle = 4k_BRT\Delta f$  also called the Johnson-Nyquist equation.
- Thermal noise is of great importance within receiver circuits where this form of noise along with other forms of noise limits the sensitivity of the receiver.
- This setup can be successfully used to calculate the Boltzmann constant which is related as  $\langle v_J(t) \rangle = 4k_BRT\Delta f$ .

## Methodology

- We studied the effect of temperature on Johnson noise by managing the temperature of the resistor at 77K, 126K, 212K and 298K with the help of liquid nitrogen and a heater.
- Measurement of temperature was assured with the help of a thermal probe which uses a 'Transdiode' as a transducer for thermal energy to electrical energy conversion.
- We also calibrated the thermal probe using the two-point calibration method.
- we plotted a graph between Johnson voltage and absolute temperature.

## Set up for the experiment

Left picture: Dewar flask containing liquid nitrogen along with Thermal Probe dipped inside it. The thermal probe is then connected to Low-level electronics as shown on the right side. Below is the image of high-level electronics which provides The final gain in signal as well as it contains a bandpass filter for our experiment.





